

EXODOR® HVAC DISODORIZER®

ODOR TREATMENT PROCEDURE

EXODOR® HVAC DISODORIZER® TREATMENT IS A PATENTED FULL-STRENGTH ODOR CONTROL PRODUCT WHICH REQUIRES NO DILUTION OR MIXING. EACH AIR HANDLING UNIT TREATED WILL REQUIRE A MINIMUM OF 32 OUNCES (1 QUART) FOR UNITS UP TO THREE (3) TONS AND PROPORTIONALLY MORE FOR LARGER UNITS TO COMPLETE THE PROCEDURE.

EXODOR® HVAC DISODORIZER® TREATMENT SHOULD ONLY BE APPLIED USING WALEX'S REFILLABLE AIR PRESSURE ACTIVATED FINE MIST SPRAYER OR OTHER APPROVED SPRAYERS. PUMP UP SPRAYERS ARE NOT APPROVED AND WILL NOT PROVIDE SUCCESSFUL RESULTS. A VERY FINE MIST IS NECESSARY TO ENSURE DEEP PENETRATION INTO THE COILS AND COMPLETE COVERAGE. THE SPRAYER SHOULD BE CHARGED WITH AT LEAST 90 PSI OF AIR. WHEN PROPERLY APPLIED, THIS PRODUCT IS HIGHLY SUCCESSFUL IN ELIMINATING HVAC ODORS. ODORS ARE USUALLY ELIMINATED COMPLETELY AND FOR THE LONG-TERM. IN SPECIAL CASES ODORS MAY ORIGINATE ELSEWHERE IN THE SYSTEM, OR MAY BE REINTRODUCED FROM OUTSIDE SOURCES. IN RARE CASES A SECOND TREATMENT MAY BE NECESSARY.

REMOVAL OF EXCESSIVE PARTICLE BUILDUP FROM COILS WILL IMPROVE PERFORMANCE OF TREATMENT BY INCREASING AIR FLOW AND ALLOWING UNIFORM COVERAGE.

BUILDINGS SHOULD BE UNOCCUPIED AT TIME OF TREATMENT AND REMAIN UNOCCUPIED FOR 30 MINUTES AFTER TREATMENT.

WEAR SAFETY GLASSES WITH SIDE SHIELDS DURING TREATMENT TO AVOID EYE CONTACT. DO NOT INHALE SPRAY DURING APPLICATION.

1. LOCATE AND EXPOSE EVAPORATOR COILS FOR TREATMENT.
NOTE: IT MAY BE NECESSARY TO CUT AN ACCESS HOLE IN THE DUCT UP-STREAM FROM COIL LARGE ENOUGH TO ALLOW COMFORTABLE ENTRY OF APPLICATOR AND A VISUAL INSPECTION.
2. TURN FAN ON TO ALLOW EXODOR® HVAC DISODORIZER® TREATMENT SPRAY TO BE PULLED THROUGH THE COIL, AND AIR HANDLING UNIT. THIS HELPS TO ENSURE DEEP PENETRATION INTO COILS.
3. SATURATE COIL THOROUGHLY FROM THE UP-STREAM SIDE BY SPRAYING COIL FROM TOP TO BOTTOM UNTIL CONTENTS OF SPRAYER (32 OUNCES) HAVE BEEN DISPENSED. USE 32 OUNCES FOR EACH 3 TONS OF CAPACITY.
4. IF ODOR PROBLEM IS EXCESSIVE, TURN OFF FAN AND SPRAY ADDITIONAL PRODUCT INTO DOWN-STREAM SIDE OF COILS AND DIRECTLY INTO BLOWER.
5. DO NOT RINSE.
6. TURN FAN OFF AFTER APPLYING TREATMENT AND WAIT 30 MINUTES BEFORE TURNING SYSTEM ON FOR USE.

CALL WALEX® AT 1 800/338-3155 FOR ADDITIONAL INFORMATION OR QUESTIONS. 10/3